

↓ HOW TO USE SNARK H.Z. ↓

1. Push tuner all the way onto guitar headstock



2. Press ON button.
3. Tune all strings.
4. Mute strings. Then press Hz button to activate Hz tuning.
 - a. Tune each string as many times as you wish, but keep going in order shown on chart below.
 - b. To cancel Hz tuning, press ON button again or wait 10 seconds for time out.
 - c. You can re-start Hz tuning by pressing the Hz button again.
5. Hint: You do not have to achieve the exact Hz frequency shown on chart.

For 6 STRING GUITARS, tune strings in ASCENDING ORDER:

	Target Hz
First LOW E	82.4
Second A	110.0
Third D	146.8
Fourth G	196.0
Fifth B	246.9
Sixth HIGH E	329.6

For 4-5 string BASS GUITARS, tune strings in DESCENDING ORDER:

	Target Hz
First G	98.0
Second D	73.4
Third A	55.0
Fourth E	41.2
Fifth B (if 5 string)	30.95

↑ HOW TO USE SNARK H.Z. ↑